

Pattern		Serial Number	Bore Mark	Weight		Length		Height at Valves		Overall Height		Bell Diameter		Bore Diameter	
				Lbs / Oz	Grams	Inches	Cm.	Inches	Cm.	Inches	Cm.	Inches	Cm.	Inches	Mm.
1	The Olds	939	LM	2 / 3.8	1017	16	40.6	5.88	14.9	6.38	16.2	4.5	11.4	0.468	11.9
2	The Standard	2033	LM	1 / 15.7	899	15.13	38.4	5.70	15.9	6.81	15.9	4.47	11.4	0.453	11.5
		2648	none	2 / 4.9	1049	15	38.1	5.63	14.3	6.44	16.4	4.75	12.1	0.453	11.5
		5621	LM	2 / 2.2	969	14.94	38.0	5.70	15.9	6.81	15.9	4.75	12.1	0.453	11.5
		8974	none	2 / 3.5	1009	14.75	37.5	6.50	16.5	7.00	17.8	4.75	12.1	0.462	11.7
3	the Military Model	1611	LM	2 / 4.5	1036	17.38	44.1	5.88	14.9	6.32	16.1	4.5	11.4	0.454	11.5
		4902	LM	2 / 6.0	1078	17.25	43.8	5.75	14.6	6.38	16.2	4.5	11.4	0.454	11.5
4	The Super	5568	none	2 / 2.2	972	16.88	42.9	5.81	14.8	6.88	17.5	4.81	12.2	0.462	11.7
		7324	none	2 / 2.9	992	16.6	42.2	5.75	14.6	6.75	17.1	4.88	12.4	0.468	11.9
		27861	none	2 / 4.1	1026	16.5	41.9	5.75	14.6	6.50	16.5	4.69	11.9	0.468	11.9
4a	The Vulcan	3766	none	2 / 4.9	1045	16.63	42.2	5.64	14.3	6.47	16.4	4.63	11.8	0.46	11.7
5	The Special (Pre-War)	6805	none	2 / 3.65	1011	16.63	42.2	6.38	16.2	7.19	18.3	4.75	12.1	0.46	11.7
	The Special (WWII Contract)	12394	none	2 / 4.4	1032	16.63	42.2	6.56	16.7	7.02	17.8	4.75	12.1	0.468	11.9
6	The Radio Model	5946													
7	The Radio Model	6570	LM												
8	The Super Olds Recording	8622	none	2 / 4.5	1034	14.25	36.2	6.25	15.9	7.25	15.9	4.88	12.4	0.468	11.9
		9039	none	2 / 3.8	1016	14.25	36.2	6.63	16.8	7.75	19.7	4.88	12.4	0.468	11.9
9	The Special (Post-War)	21406	none	2 / 3.3	1002	14.94	37.9	6.38	16.2	6.81	17.3	4.75	12.1	0.468	11.9
		90932	none	2 / 6.2	1084	15.25	38.7	6.25	15.9	6.90	17.5	4.75	12.1	0.468	11.9
10	The Ambassador	30154	none	2 / 4.9	1048	15.25	38.7	6.50	16.5	6.75	17.1	4.75	12.1	0.468	11.9
11	The Studio	57764	none	2 / 6.1	1082	15.44	39.2	6.25	15.9	7.06	17.9	4.5	11.4	0.468	11.9
		133333	none	2 / 5.0	1051	15.44	39.2	6.50	16.5	7.00	17.8	4.56	11.6	0.468	11.9
12	The Recording	57357	none	2 / 7.1	1110	14.38	36.5	6.75	17.1	7.50	19.1	4.63	11.7	0.468	11.9

NOTES:

Weight is measured without mouthpiece but with all stop rods, finger rings, thumb saddles, etc.

Length is measured from the bell to the rear of the bell crook or the receiver (whichever is longer), without mouthpiece.

Height at Valves is measured from the bottom of the casing to the top of the button, with the valves uncompressed.

Overall height is measured from the bottom of the valve casing to the highest point of the bell.

Bell diameter is measured at the outside of the widest part of the flare.

Bore diameter is measured at the second valve slide.